

Bump cap strap installation for RealWear HMT-1



How to mount the strap to the glasses:

1. Determine the side the device will be worn on. The photos accompanying these instructions show a right-eye configuration
2. Fold the boom arm all the way down and back
3. Lay the headset on a table with boom arm laying on table



4. Lay the t-strap over the headset with the button snap on the rear headband and the tri-glide buckles facing up.



5. Wrap end around the rear-part of the headband and snap shut



6. For this step, it may be easier to flip the device and strap over.
- We recommend that you attach the non-camera/non-boom side of the device first as this will be the easier side to attach.
 - Ensuring that the strap is not twisted and that the snap buckle flange faces toward the center of the device push the snap buckle into the slot at the front of the device.
 - You may need to angle the buckle toward the center of the device and wiggle the buckle into place
 - The buckle will snap into the metal band. When fully snapped in, the flange can be felt protruding above the flat surface of the metal band.



7. Repeat for the other side of the HTM-1.

How to mount the glasses til the bump cap

8. Fit the HMT-1 and strap over the top of the bump cap so that the hull of the HMT-1 is approximately even with the bottom edge of the cap.



9. Attach the brim clips - one on each side of the strap, close to the buckles - underneath the brim of the cap.



10. If necessary throughout the process, adjust the length of the straps to conform to the size and shape for the cap.

The finished result should look like this...

